

ACME Procedure		OPS-0002-B	
Title:	ACME Unit 1 Warm Start procedure		
Author:	R.J.Smith	Authorised by:	<i>John Hancock</i>
Review Date:	1 January 2027	Date Authorised:	17 March 2025
Associated Documents:	None		

Rev	Date	Author	Authorised By	Modification	Status
A	1 Jan 2025	R.J.Smith	J. Hancock	First draft	Draft
B	17 Mar 2025	R.J.Smith	J.Hancock	Finalised	Issued

Summary

This procedure provides a step by step instruction for ACME Power Unit 1 start up from warm conditions. It shall be used as a reference each time this plant is started and a record kept of plant start up progress and any issues, events or error for future improvements.

On ACME Power Unit 1, a warm start is one in which the steam turbine rotor temperature as measured at thermocouple 1MAB10CT005 is >250 and <450 deg C.

Warm Start

The main differences compared to a cold start are;

- Auxiliary plant is already running.
- Need a higher steam temperature, pressure and flow from the boiler to match the steam turbine requirements.

A step by step procedure so as to accomplish a warm start is below and this should be followed as closely as possible to achieve the best possible score.

1. CHECK circuit breaker 1ADA10GS001 to backfeed power to 11kV electrical board 1BBA10 (0AEA10GH001 ON).
2. CHECK plant fuel oil supply system (0EGC10AP001 ON).
3. CHECK gland steam supply is available. If not then START the auxiliary boiler (0QHA10GH001 ON).
4. CHECK turbine lube oil pump (1MAV10AP001 ON).
5. CHECK turbine jacking oil pump (1MAV20AP001 ON).
6. CHECK turbine turning gear (1MAK10AE001 ON).
7. CHECK condensate extraction pump (1LCB10AP001 ON).
8. CHECK condensate extraction pump controller in AUTO (LCB (CEP-AUTO)).
9. CHECK feedwater pump (1LAC10AP001 ON).
10. CHECK feedwater pump controller in AUTO (LAC (FWP-AUTO)).
11. CHECK condenser cooling water pump (1PAB10AP001 ON).

12. CHECK gland steam system (1MAW10GH001 ON).
13. CHECK condenser vacuum pump (1MAJ10AP001 ON).
14. START furnace fans;
 - (a) CHECK air heater (1HLD10AC001 ON). Air heater speed should be around 3 rpm.
 - (b) START induced draught fan (1HNC10AN001 ON).
 - (c) START forced draught fan (1HLB10AN001 ON).
 - (d) SELECT furnace air flow controller (AirFlow (AUTO)) to automatic.
15. PURGE the furnace (PURGE button).
16. START fuel oil burner (1HHA10AV001 ON).
17. INCREASE fuel oil burner controller (1HHA10CQ001) to 100%.
18. ADJUST furnace burner tilt angle (1HFD10GF001a) to ensure superheater outlet temperature (1LBA30CT001) is $430 \text{ deg C} \pm 20$.
19. CHECK turbine bypass valve (1MAN20AA251) will OPEN after a short period.
20. When the following turbine steam inlet condition are met the turbine can be started;
 - (a) main steam temperature (1LBA60CT001) $430 \pm 20 \text{ deg C}$.
 - (b) main steam pressure (1LBA60CP001) $110 \pm 10 \text{ bar}$.
 - (c) main steam flow rate (1LBA50CF001) $\approx 25 \text{ kg/s}$.
21. CHECK turbine control oil pump (1MAX10AP001 ON).
22. RESET turbine trip.
23. CHECK generator synchronising circuit breaker (1MKA10GS001) has closed.
24. CHECK turbine load increases to minimum continuous load of approx. 15 MW (gross).
25. SELECT Turbine CTRL mode to "Turbine MW AUTO".
26. START primary air fan (1HFE10AN001 ON).
27. START coal pulveriser B (1HFC20AV001 ON).
28. START electrostatic precipitator (1HDE10AT001 ON).
29. INCREASE pulveriser B coal flow controller (1HFB20CQ001) to 20 t/hr.
30. START coal pulveriser A (1HFC10AV001 ON).
31. STOP fuel oil burner (1HHA10AV001 OFF).
32. INCREASE pulveriser A and pulveriser B coal flow controller (1HFB10CQ001 and 1HFB20CQ001) to 40 t/hr each. This should be done slowly whilst being mindful of boiler limits on rate of increase for pressure and temperature.
33. ADJUST furnace burner tilt angle (1HFD10GF001a) to ensure superheater outlet temperature (1LBA30CT001) does not exceed design values (design = 540 deg C ; alarm = 545 deg C ; trip = 555 deg C).
34. STOP plant fuel oil supply system (0EGC10AP001 OFF).
35. Increase boiler fuel firing until unit full load (approx. 150 MW gross) is reached.

Disclaimer

This document is provided by Richard J Smith 'as is' and 'with all faults'. The provider makes no representations or warranties of any kind concerning the safety, suitability, inaccuracies, typographical errors, or other harmful components of this document and software.

The sole purpose of this document is to provide a guide to the accompanying application.

Use the information contained at your own risk.