



Let's increase Unit 2 AVR Mva setpoint to +1 Mvar. Unit 1 will automatically respond by reducing its Mvar setpoint to ensure the same total is exported to meet demand.

Total MW	U1		p.f.	Current	U2		p.f.	Current
	MW	MVARs			MW	MVARs		
56.50	39.55	31.70	0.78	4607.78	16.95	0.00	1.00	1541.01
56.50	39.55	30.70	0.79	4551.48	16.95	1.00	1.00	1543.69

